

Table 2 Alarms

Code	Description
CF 0 - CF 9	Position of configuration switch S1. Certain parameters can be modified only when S1 = 0.
AL 1	Parameter upload/download failed.
AL 2	Operation not allowed while start is active.
AL 3	Operation not allowed in remote or local control.
AL 4	REVERSE button disabled. Parameter 208 (Dir Lock) is active.
AL 5	Panel START button disabled. DI configuration is 3-wire and DI2 is open.
AL 6	Operation not allowed. Parameter 503 (Param Lock) is active.
AL10*	Overcurrent controller active.
AL11*	Overvoltage controller active.
AL12*	Undervoltage controller active.
AL13	Reserved. Contact supplier.
AL14	Reverse command attempted in remote control (REM), while parameter 208 (Dir Lock) is active.
AL15 - AL16	Reserved. Contact supplier.

Note! Alarms (*) will be shown only if parameter 506 is set to 1 (Yes).

Table 3 Faults

Code	Description
FL 1	Overcurrent: <ul style="list-style-type: none"> Possible mechanical problem. Acc and/or Dec times may be too small.
FL 2	DC overvoltage: <ul style="list-style-type: none"> Input voltage too high. Dec time may be too small.
FL 3	ACS 100 overtemperature: <ul style="list-style-type: none"> Ambient temperature too high. Severe overload.
FL 4 *	Fault current: output earth fault or short circuit.
FL 5	Output overload.
FL 6	DC undervoltage.
FL 7	Analogue input fault. (See parameter 501.)
FL 8	Motor overtemperature. (See parameter 502.)
FL 9	Panel disconnected from drive in local control. Note! If FL 9 is active when the power is turned off, the ACS 100 will start in remote control (REM) when the power is turned back on.
FL10	Parameters inconsistent. Check that AI min (f_{min}) is not greater than AI max (f_{max}).
FL11 *	DC bus ripple too large. Check supply.
FL12	Reserved. Contact supplier.
FL13 - FL14*	Hardware error. Contact supplier.
FL15*	Analogue input out of range. Check AI level.
FL16-FL19*	Hardware error. Contact supplier.
Full display blinking	Serial link failure. Bad connection between the control panel and the ACS 100.

Note! Faults (*) with red blinking LED are reset by turning the power off and on. Other faults are reset by pressing the START/STOP button.